CHECKLIST OO-RAQ

BEFORE STARTING ENGINE

Tow bar Pre-flight check Ship's papers Weight and balance

Seats and belts

Doors

All switches & avionics

Throttle Mixture

Carburettor heat

Master switch Warning lights

Engine instruments

Fuel level Fuel valve

Primer Mixture

Throttle Toe Brakes

Propeller area

Start engine

Removed Completed On board Checked

Adjusted and locked

Locked

OFF IDLE LEAN COLD

ON Check

Check readings

Check fuel quantity indicator

BOTH

As required, check locked

Full RICH

Cycle once, then 5 mm open

ON

Check Clear

BEFORE TAXYING

Throttle Oil pressure Alternator switch 1200 rpm

Check pressure in green

ON

Check low volt warn. light out

Radio's

Transponder Flaps

Strobes Trim

Check positive amps on Mon

ON

Squawk '7000', Standby Check operation, then UP

ON

Check & set Controls Free & correct

TAXI

Parking brake **Engine instruments** Brakes and steering Gyros

OFF

Check readings

Check Check

BEFORE TAKE-OFF

Doors Toe Brakes

Throttle

Mixture

Magnetos

Check locked ON

1800 rpm Check L/R/Both

Carburettor heater Check Suction gage Check

Throttle IDLE, 600-800 RPM Throttle

1000 rpm, magnetos on/off Flight instruments Check **Engine instruments**

Check **Full Rich**

Magnetos Both Carburettor heat COLD

Flaps Set for take-off Fuel selector BOTH

Landing light ON

Red lights None

WHEN CLEARED FOR TAKE-OFF

Approach area Directional gyro Pitot heat

Look for other aircraft Set on runway QFU

As required

Apply

Up

WHEN AIRBORNE

Toe brakes

Flaps Landing light Transponder

OFF Squawk Mode C **DOWNWIND**

Engine instruments Mixture Fuel selector

Carburettor Heat Speed

Slow down to 70 kts Set 10 dea

Check

BOTH

HOT

Full rich

FINAL

Flaps

Carburettor heat Flaps Speed

Set 20-30 deg, as required 60 kts

UP

OFF

OFF

COLD

AFTER LANDING

Flaps Landing light Pitot Heat

Transponder Standby Trim Neutral Mixture Adjust to lean

SHUTDOWN

Throttle 1000 rpm Avionics **OFF** OFF All lights & switches

Mixture Full lean Master switch **OFF** Alternator switches

OFF

OFF, remove key

Magnetos OFF Fuel valve